

HCC 液晶顯示電腦密碼鎖保險箱使用說明

一. 開始方法

1. 系統上電後，顯示屏自動掃描，液晶屏交替顯示黃色、藍色背光，掃描後屏顯“GOOD”，蜂鳴器演奏“DO，RE，MI，FA，SO，LA，XI，DO（H）”，然後進入待機狀態。
2. 待機時，系統顯示日期、時間及電壓狀態。此時，需要重新校對日期和時間。

二. 開啟保險箱

1. 在待機狀態下，按“#”鍵喚醒，液晶屏顯示黃色背光和“———”時，可輸入1~8位個人密碼，再按“#”鍵確認。（若輸入的密碼為8位數，系統將自動確認）
2. 如果密碼正確，則顯示“OPEN”液晶屏切換成藍色背光，蜂鳴器演奏“DO，RE，MI”，請在5秒內順時針旋轉鑰匙並向外拉，即可開啟保險箱。
3. 如果密碼不正確，則顯示“ERROR”，蜂鳴器演奏“SO，SO，MI，SO，SO”，然後重新顯示“———”，此時可重新輸入密碼。
4. 如果連續3次輸入密碼有誤，屏幕顯示報警喇叭標誌，報警一分鐘。輸入正確密碼後按“#”鍵，液晶屏背光進行切換，即可解除報警。然後轉入待機狀態。
5. 每次輸入密碼正確的開門記錄將被保存。

三. 鎖閉保險箱

關閉保險箱，轉動鑰匙或旋鈕即可。

四. 用戶密碼的設定和更改

1. “OPEN”換碼法：先用個人密碼開門，當屏幕顯示“OPEN”液晶屏切換成藍色背光時，按“*”鍵，則系統進入修改個人密碼狀態，顯示“———”。此時可輸入1~8位新的個人密碼，再按“#”鍵確認（輸入8位密碼，系統自動確認）。屏幕上顯示“in”，同時蜂鳴器演奏“MI，RE，DO，RE，MI”，表示密碼修改成功。
2. “換碼鍵”換碼法：打開箱門。在待機狀態下，按一下門後面的AN鍵，液晶屏顯示藍色背光和“———”。此時可輸入1~8位新的個人密碼，再按“#”鍵確認（輸入8位密碼，系統自動確認）。屏幕上顯示“in”，同時蜂鳴器演奏“MI，RE，DO，RE，MI”，表示密碼修改成功。
3. 密碼修改成功後，屏幕將再次顯示新密碼，1秒後回到待機狀態。

五. 查詢開門記錄

1. 先用密碼開門。當屏幕顯示“OPEN”液晶屏切換成藍色背光時，按“0”鍵，或“8”鍵，可查詢以前的開門記錄。每條記錄分兩屏顯示。
2. 先顯示第 1 屏：密碼類別（例如：“PASS - 1” / “PASS - 2”）和記錄號（例如：“NO 01”為最近一次的開啟記錄、“NO 58”為最遠一次的開啟記錄）；
3. 然後顯示第 2 屏：該記錄的開門日期及時間。
4. 記錄翻頁：在查詢狀態下，按“0”鍵上翻記錄；按“8”鍵下翻記錄。
5. 記錄清除：在查詢狀態下，按紅色按鈕，顯示“CLEAR”，所有記錄被清除。
6. 系統最多可保存 58 條記錄。超過時，每增加一條新記錄，最早的一條記錄將被覆蓋。

六. 修改系統日期

1. 待機狀態下，按“*”鍵，液晶屏為黃色背光進入修改系統日期時間狀態。
2. 直接按數字鍵，輸入“年” - “月” - “日”，“星期”，“時”：“分”（共 11 位數）（相應的設置位閃爍）後，自動確認，保存新的時間並退出設置狀態，回到待機狀態。
3. 設置途中，按“*”鍵，後退一格，可重新輸入。
4. 系統會對輸入數字有效性進行鑒別，起過範圍的無效數值不予以確認。各個參數有效範圍如下——年：00~99；月：01~12；日：01~31；星期：MON~SUN；時：00~23；分：00~59。
5. 系統內嵌 2000 年 2099 年的萬年曆，計時時會自動進行大小月切換和閏年轉換。

*在修改日期時，用戶必須確保輸入的日期正確有效。

七. 保險箱的應急開啟

1. 若用密碼無法開啟時，可採用應急開啟。
2. 向右推開電池盒蓋，取下電池後，將應急鑰匙插入應急鎖孔並逆時針旋轉至限位，再順時針轉動主鎖鑰匙，開啟保險箱。

*應急鑰匙不可放入您的保險箱內

八. 震動報警功能

1. 待機狀態下，按“0”鍵，屏顯“ALERT on”並進入警戒狀態。保險箱受到振動後，就會立即報警，屏幕顯示報警喇叭標誌和“—————”。
2. 輸入正確密碼，屏顯“OPEN”液晶屏切換成藍色背光，停止報警，解除警戒狀態。

*警戒狀態有效時，執行一次正確的開門動作，就會撤消警戒狀態。

九. 隱碼、清除和系統自動返回功能

1. 隱碼功能：在輸入密碼之前，先按“*”鍵，可切換隱碼功能，(單次按下隱碼有效；雙次按下時，隱碼無效)。隱碼有效時，輸入數字屏幕不會顯示，而以“0”代替。
2. 清除功能：在輸入和修改密碼過程中，每按一次“*”鍵，可清除最後輸入的一位數字。
3. 系統自動返回功能：在進行開啟、設定、查詢和修改系統日期時，若操作未完成，且 10 S 內未有後續操作，系統自動退回待機狀態。

十. 電池的使用與更換

1. 請使用四粒 1.5V 電池。液晶屏左側顯示有電池標誌。電力不足時電池標誌顯示為空心，並會導致開門時屏顯“LO - BATTE”，表示欠壓，提醒您更換電池。請及時更換電池。
2. 斷電後再次上電時，應重新校對時間。

*請在 5~40°C 的溫度範圍內使用本產品。

HCC Safe Instruction Manual

How to Use

Insert four AA batteries into the battery box. Then, The LCD screen lights up and displays the current time. Insert the key and press the “#” key, enter “1234” and press “#” key again to confirm. The screen display “OPEN”. Turn the key right, open the door within 5 seconds.

Enter the password

Press the key “#” to enter the password input state. Press the numbers “0-9” to input the password. If there is no operation within 10 seconds, the backlight will turn off.

The key “*” is used as the deleted key at this point. When the first digit is flashing, press the key “*”, and the password entered will be displayed in hidden code until the end of this operation. The initial state will be resumed in next operation

When the password input is completed, press the key “#” to confirm the password. (Note: the operation will be void if no password input)

If the password is incorrect, an error tone will be given and the prompt “Error” is displayed. The system will re-enter the password input stated within 3 seconds.

When the password is incorrect for three times consecutively, all the backlight will turn off, alarm is given and lasts for one minute. The operation will continue after the alarm sound lasts for 10 seconds. (In order to stop the alarm, you need to re-enter the correct password)

If the password is correct, a tone indicating success will be given and “OPEN” is displayed. If there is no operation within 5 seconds, the backlight goes off.

Change Password

Press the key “#” then enter to the password input state, enter the correct password. When the LCD screen displays “OPEN”, press the key inside the door right side order to enter the password change state.

The password can be set for 1- 8 digits. When the password is entered, press the key “#” to confirm. A tone indicating success will be given and “IN” is displayed. The new password is done.

Record Search

When the LCD screen displays “OPEN”, press the key “0” or “8” and enter to the record search state. When the screen displays the “PASS-01” / “PASS-02”, the key “0” and the key “8” are used to search the record up and down respectively. Then press the red key, you can delete all the record. (The system can record up to 58 records, exceeding which, the old record will be over written.)

Setting of time

Press the key “*” to enter the time setting mode before the LCD screen lights up. You have to enter the year, month, date, week, hour and minute. If those information are incorrect, press the key “*” can erase and re-enter those information. After the last digit is set, a tone will be given to indicate successful setting of time. Then the new time will be displayed. (The system will calculate the weeks automatically.)

Hide the password

Press the key “*” to enter the time setting mode after the LCD screen lights up. Insert the password will hide the number.

Vibration alarm

Press the key “0” start the state of the vibration alarm.

After turn on the vibration alarm, if the several vibrations are continually detected within two seconds, then the alarm is given and lasts for one minute.

If you need to turn off the vibration alarm, press the key “#” after the alarm is lasted for 10 seconds and enter the correct password. The alarm will be turned off.

Changing Battery

When the LCD screen displays  , please change the battery.